

Manufacturers Recommended Rough Opening Sizes:

European Tilt & Turn Window

These sizes are based on using 2"X pressure treated wood all the way around the rough opening. Thereby creating a wooden window buck that you will be attaching the window to. These size recommendations are designed to leave roughly a 1/8" space all the way around the window to allow for shimming.*

Window Size	Recommended Rough Opening Size
28" W x 46" H	31 ½" W x 49 ½" H
31" W x 41" H	34 ½" x 44 ½" H
35 ½" W x 36" H	39" x 39 ½" H
28" W x 52" H	31 ½" W x 55 ½" H
27 3/8" W x 46" H	30 7/8" W x 49 ½" H
29 3/8" W x 47 ½" H	32 7/8" W x 51" H
31 3/8" W x 47 ½" H	34 7/8" W x 51" H

* These measurements are assuming that your rough opening is square, level and plumb.